

**OPERATING INSTRUCTIONS
FOR**

FIBEROPTIC

DISPLACEMENT MEASUREMENT SYSTEMS

DMS

**Type D - Reflectance Dependent
Type RC - Reflectance Compensated**

Model DMS-

Serial No.



PHILTEC, INC.

www.philtec.com

Precision Dynamic Measurements

IMPORTANT:

1. Sensor tips and fiberoptic cables are provided in a variety of sizes and materials, some of which are rugged and others which are very fragile. It is important to handle sensor tips and cables with care, as they are not subject to warranty if damaged.

2. Always ensure that the sensor tip, target area and optical path are clear and clean. Accurate motion amplitude measurements are dependent upon the precise reflection of rays of light from target surfaces. Lint, dirt, or debris particles can obstruct, diffract or reflect light rays in unpredictable directions, thereby compromising the achievable accuracy of these devices. Sensor tips can be cleaned with alcohol and a soft cloth or tissue.

SOFTWARE & FIRMWARE UPDATES

DMS sensors can be updated remotely at any PC.

The most current edition of Philtec's DMS Operating & Control Software and the microprocessor's firmware program are posted at <http://www.philtec.com/firmware.htm>

WARRANTY

Displacement Measurement Systems are warranted by Philtec, Inc. against defects and workmanship for 12 months from the date of shipment from the factory. Damage to the fiberoptic cable or sensor tip are not covered under this warranty.

Description

Displacement Measurement Systems (DMS) are microprocessor-based systems for providing direct outputs of distance using RS-232 protocol. They are comprised of:

- Fiberoptic Light Guides To Develop Analog Input Signals
- Digital Processing Units with storage capacity for 24 calibrations per channel
- Keypad/front panel display for local operation
- RS232 output for remote operation


Power Requirements

DMS Single Channel: 12 VDC @ 350mA

DMS Dual Channel: 12VDC @ 450mA




Fiberoptic Light Guides




D Type Sensors

D Type Sensors are recommended when the target moves along the axis of the sensor; i.e., single axis vibration where the target reflectivity is constant.



OPERATING PRINCIPLE. Light is transmitted to the target thru glass fiberoptic bundles. The intensity of reflected light returns thru the reflectance dependent fiberoptics to the DMS where it is precisely measured and compared with 24 bit resolution to stored calibration data. The return signal intensity varies with target motion and will also vary proportionately with target reflectivity variations. Therefore, these devices are most commonly used where the target reflectance remains fixed, such as in single axis stroke, displacement or vibration parallel to the axis of the sensor. Precise scaling of the reflectance dependent signal amplitude is accomplished by capturing and setting the optical peak power level with the DMS.



RC OPERATING PRINCIPLE. Fiber optics transmit light to the target where it reflects back thru two independent groups of receiver fiber optics in the sensor tip. The reflected light intensity in the two receivers are processed ratiometrically in the DMS, compared with 24 bit resolution to stored calibration data. The ratio function of the intensity of reflected light provides the distance measure which is independent of target reflectance variations; i.e., **reflectance compensated.**


SENSOR TIP FIXTURING and ALIGNMENT - RC Models

1) ALIGN THE SENSOR TIP

RC sensors have adjacent fiber bundles in the face of the sensor. Note there is an alignment flat on the casing to aid with alignment. The flat is ground parallel to the split between the adjacent fiber-optic bundles.

Depending upon the application, there may be a preferred orientation for best performance. For example:

- If the target is cylindrical, it is usually best to mount the sensor with the X axis parallel to the cylindrical axis
- If there is lateral motion, it may be preferable for the direction of motion to be parallel to the x axis
- The sensor is 10 times more sensitive to tilt about the Y axis than the X axis. If tilt is directional, orient the sensor so that the target pivots about the sensor's X axis.
- If targets are discontinuous, voltage spiking at the leading and trailing edges of the parts will occur when the direction of travel is parallel to the X axis. The voltage spiking is eliminated when the direction of parts travel is parallel to the Y axis.
- For smooth and continuous flat surfaces, sensor tip orientation is not critical.



2) MOUNT THE SENSOR, so that the tip is perpendicular to the target surface.

NOTE: The collar and tip are not exactly parallel to each other. For factory calibrations the tip is clamped square to the target. For best accuracy, clamp to the probe tip and not to the collar.

Calibrations

Two factory calibrations are provided with each sensor channel: a mirrored (specular) target and a dull (diffuse) target. The calibration data is stored on board each sensor in separate calibration tables. Hard copies of each calibration chart are provided under separate enclosure.

Additional calibrations (up to 24) can be stored per channel.

Communication

Communication with sensors is conducted thru one RS232 port. Multiple units can be daisy-chained together.

The RS232 pins are standard:

From a PC:

Pins 1, 7 & 9 = not connected

Pin 2 = Receiver

Pin 3 = Transmitter

Pins 4, 6 & 8 = connected all together

Pin 5 = Ground

(From the DMS: pin 2 = transmit; pin 3 = receive)

Temperature Stabilization

The amplifier is equipped with a temperature stabilization feature.

Procedure - Apply power to the sensor and allow the amplifier time to reach thermal equilibrium, about ½ hour or more. Increase the Set Temperature 2 - 3 degrees above the equilibrium temperature. The amplifier temperature will be maintained at the set temperature ± 0.1 °C.



Notes:

- 1. If the amplifier temperature creeps above the set temperature by more than 0.1 degree, further increase the set temperature to reach a stable and controllable temperature set point.*
- 2. This heater circuit has limited heat flow capacity. If the active temperature drops below the set temperature, which may happen when the ambient temperature drops significantly, reset the control to 2-3 degrees above the lowered equilibrium temperature.*
- 3. The sensor should be kept thermally isolated from its mounting base.*

OPERATING RANGES AND GAPS

Calibration data is stored on-board each sensor. This means the sensor can be gapped for measurements anywhere within the sensor's total operating range.

As with all type D fiberoptics, optimum performance is achieved where signal-to-noise is greatest; i.e., where the D function has the steepest slope (greatest sensitivity). A sensitivity chart is included with every sensor calibration showing its D function vs. Distance. When optimum performance is desired, refer to that chart to determine the optimum gap settings.




FACTORY CALIBRATIONS AND ACCURACY

Each sensor is been calibrated using a 0.2 micron accuracy linear air bearing stage.

Procedure


1. Mount the target on the stage table.
2. Mount the sensor off the stage table. The target moves during calibration. The sensor is stationary.
3. Begin with the sensor making light contact with the target.
4. Move the stage with target away from the sensor in small steps covering the total operating range.
5. After each step move, a) the stage position is read from the stage encoder and b) the sensor outputs are read. These two data are stored in the designated calibration slot.
6. Then, without disturbing the setup, the stage is moved back to its original position using the same steps. This time, the stage position is read from the sensor at each calibration step.
7. Repeatability is a measure of the accuracy of the sensor. A chart is prepared for each sensor calibration, where the repeatability data is graphed over the sensor's operating range. These charts graph the difference between the stored calibration (data moving away from the sensor) and the read data on the return moves.



REFLECTIVE NATURE OF THE TARGET SURFACE


1. Specular Targets...*A mirror surface calibration should be used when making measurements to mirrored surfaces.*

A factory supplied calibration to a specular target is stored in cal slot #1, where the target is a front surface mirror. This calibration should be used if the target surface is any highly polished, mirrored, glossy or very shiny (specular) target. Thin transparent materials require their own calibration, which should be stored in a separate slot.



2. Diffuse Targets... The surface looks dull rather than shiny. *A diffuse surface calibration should be used when making measurements to diffuse surfaces.*

A factory supplied calibration to a diffuse reflector is stored in cal slot #2, where the target surface is anodized aluminum. With diffuse surfaces, reflected light rays travel randomly varying path lengths back into the sensor tip. Reflectance compensation does not correct for random scattering of light rays, which can lead to measurement errors.



So, for diffuse target surfaces, which include anything with a dull, flat or matte finish, as well as those with machined, honed or ground finishes:

- Use the diffuse calibration or
- Calibrate the system to the target material and store in a separate cal slot.

MATERIAL	% REFLECTANCE
Gold Mirror	100
Mirror Polished Aluminum	85 - 90
Mirror Polished Stls Stl	60 - 70
Brushed Aluminum	40 - 50
Copper Clad PC Board	45
Finely Ground Steel	30 - 35
Anodized Aluminum	20 - 25
Silver Paint, Glossy	15 - 20
Photo Paper, High Gloss	15
inkjet Paper, Bright White	7 - 8
Fiberglass, Glossy	7
Black Plastic, Glossy	6
Black Matte Finish	3
Column of Water	2
Flat Black Rubber	1

The table here shows the relative reflectance of some common materials.

Remote Operation via PC

1. **Apply power to the sensor.**
2. **Load into PC & Execute** the DMS Control Software provided. The sensors will first go thru an initialization routine. During this process, in addition to many other checks, the software reads and copies all of the calibration tables from the sensor.
3. **Allow the sensors time to reach thermal equilibrium**, app. 20 minutes. For example, in a factory environment, where the air temperature has been around 24 C, the sensor temperatures rise to about 32 C. Therefore, the heater controls should be set to 2-3° C higher in each sensor. They are very stable at this set point.

NOTE: The temperature set point may require higher or lower set temperatures depending upon the factory temperatures in winter and summer months.

The Set Temperature should be 2 - 3 degrees above the equilibrium temperature. The amplifier temperature will be maintained at the set temperature ± 0.1 °C. If the amplifier temperature creeps above or below the set temperature by more than 0.1 degree, change the set temperature to reach a stable temperature set point.


4. The sensors are now ready to make measurements.

DMS Control Software

The DMS Control Software opens at the **Com Port** tab.


Opening One Sensor

1. To open a single sensor, go to "**Single Channel**" tab and select the com port from the drop down list.
2. Click Open Com Port
3. Dual Channel DMS units are opened at the "**2DMS....**" tab.



Opening Multiple Sensors on One Com Port

1. At the **"10DMS"** tab select the com port from the drop down list.
2. At "Number of Channels, enter the number of sensors to open.
3. Enter the sensor serial numbers
4. Click Open Com Port




Opening Multiple Sensors on Multiple Com Ports

1. At the **"Multiple Com"** tab enter the number of com ports to open.
2. At "Com Ports", in each open window, select a com port from the drop down list. Then enter the number of sensors to open.
3. Click Open Com Port

NOTE

Each com port can only open one sensor in this mode.



SETUP & CONFIGURATION

Use the **Configuration Tab** to setup the sensor for measurements. The sensor should be fixtured in place perpendicular to the target to be measured. Click Title Bar of each section for instructions.

1. **Channel Select:** select the sensor channel or the sensor serial number.

NOTE: The software will recognize the type sensor. If the sensor is a RC type, the Reflectance Peak Set block will be locked out. The Reflectance Peak Set block becomes active when the sensor selected is a D type.

2. **Temperature:** Use the slide controls to set the temperature of the electronics. For best accuracy with slow speed applications, allow the unit to reach steady state temperature prior to making any measurements. This can take 15 - 30 minutes. If the heater is not needed it can be turned off (set to 0) to reduce power consumption.

3. **Calibration Select:** choose the appropriate calibration data table for the target to be measured.

4. **Optical Power:** The Transmit power is always full on. The Received power varies with the sensor's gap to target.

5. **Reflectance Peak Set:** the sensor must be scaled (calibrated) to the reflectance of the target to be measured. There are two methods:

- Manual - Adjust the sensor gap for maximum 'Reflect Value' and press 'Peak Set'. This will lock in the reflectance value in the 'Reflectance Peak' window.
- AutoPeak - Press 'Peak Hold' and move the sensor tip slowly thru the peak reflectance value. The reflectance peak will be captured and held in the 'Reflectance Peak' window.

6. **Reset Gap.** After setting the reflectance peak value, reset the operating gap to the desired starting point for measurements on the Near Side or the Far Side.






Chart Data



This live graph displays data with selectable point density from 50 - 4000 points on an autoscaling chart.


AUTOSCALING

The chart can be cleared at any time and it will restart autoscaling the current input data. Autoscaling can be turned off at any time. When autoscaling is off, the minimum and maximum points are displayed. The user can enter any value in the min-max windows.



PEAK-TO-PEAK

Peak-to-peak displays the difference between the maximum and the minimum value of the points displayed on the live chart. If 50 points are displayed, this is the pk-pk reading of 50 points. If 4000 points are displayed, it is the pk-pk reading of 4,000 points.




TARED READINGS

A Tare Function is included in the Live Chart Display.

- In the TARE WINDOW click 'Tare Reset' to activate tared readings.
- With Tare Scale ON, the live chart displays the tared values.
- With Tare Scale OFF, the live chart displays the untared values.
- The Tare Window displays the Maximum and Minimum tared values as well as the Max.-Min. difference (pk-pk tared reading).


Max - Min is the pk-pk value of the tared readings. This value holds until the tare is reset.

Note: *Tare Reset can only be done at the Configuration Tab.*



AVERAGE


DMS sensors have an internal sampling rate of 20 KHz; miniDMS sensors have a 40 KHz clock rate. The average filter controls how many readings the sensor will average together before sending the results to the serial port. Higher averages will slow down sensor response and increase resolution. The actual sample rate (readings/second) is displayed below the live chart. The maximum achievable data rate is limited by the serial connection. At the slowest speed (4096), the sample rate is approximately 10 readings per second for mini-DMS sensors and 5 r/s for DMS sensors. For the highest speed, use the Data Stream tab.




GRAPH DISPLAY

At Graph Display, select one parameter to chart from the drop-down list:


- Distance - select units of measure at Distance UOM*
- Reflection % -compares the target material to the reflectivity of the calibration table selected
- Temperature - sensor amplifier temperature, °C
- Sensor Curve - raw sensor curve generally used for factory diagnostics
- Receive Power - the amount of optical power received from a target



* Select Distance UOM (*Units of Measure*):
microns or mm (millimeters), or inch or mI (milliInches)



SAVING DATA TO FILE



There is a common interface at each tab for saving data to a file. Click **Browse** to name a data file. NOTE: Use the file extension .txt. Use Excel to open the text file.

- **Delay** - dial in the number of seconds desired between data points. Default = 0 seconds
- **ON/OFF** - Click the OFF button to start taking data. The button state will change to ON. The # of points saved is accumulated in the *Points Saved* window. Click the ON button to stop recording data. The button state will change to OFF. Data collection can be restarted by pressing the ON/OFF button again, and the data will be added to the same data file.

The table below shows a sample of the data recorded. Note the column headings give the sensor serial number and channel number.

- Time Stamp - An absolute time stamp: the # days starting 01/01/2000
- Delta T - The amount of time between successive data points, accurate to approx. 1 microsecond
- Raw Sensor Output - A factory diagnostic
- Signal Power - % Optical Power returned from the target
- Temperature - Amplifier temperature, °C
- RC/D Near Distance - Distance for an RC sensor or the Near Side for a D sensor
units of measure = previous set from live graph
- D Far Side Distance - Distance on the Far Side for a D sensor
units of measure = previous set from live graph
- Reflect Percent - reflectivity of the target material compared to the calibration table selected

Note: Time stamping data points enables post processing applications such as fft analysis.

start:1/1/2000	679 / 1	679 / 1	679 / 1	679 / 1	679 / 1	679 / 1	679 / 1
Time Stamp (days)	Delta T (sec)	Raw Sensor Output	Signal Power	Temperature	RC/D near Distance	D far side Distance	Reflect Percent
3092.415247	0.019584	3.630522	10.588235	27.75	3175	0	69.230766
3092.415258	0.017856	3.630842	10.588235	27.75	3175	0	69.230766
3092.415317	0.021408	3.631108	10.588235	27.8125	3175	0	69.230766
3092.415318	0.018912	3.63085	10.588235	27.8125	3175	0	69.230766
3092.41533	0.021936	3.630989	10.588235	27.75	3175	0	69.230766
3092.415341	0.019872	3.631088	10.588235	27.8125	3175	0	69.230766

MULTI-CHANNEL CONFIGURATION

The **Multi Configuration** tab simultaneously displays data from as many as 10 sensor channels. For single channel units, only one column is active. At this tab you can control or set the following individual sensor variables:

- data average
- transmit power
- amplifier set temperature
- calibration slot

The screenshot displays the 'Multi Configuration' tab of the 'DMS Setup and Control (version 1.19)' application. The interface is organized into a grid of 10 columns, each representing a sensor channel. Each column contains several adjustable parameters, each with a numerical input field and a small up/down arrow icon. The parameters and their values for the first three active channels are as follows:

Serial	Average	Transmit%	Receive%	Set °C	Live °C	Calibration	RC/ D near	D Far	Reflect%
521	4096	100	5.9	38	38.0	1	0.0000	3048.0	7.9
379	4096	100	5.9	38	37.9	1	0.0000	3048.0	8.6
378	4096	100	5.9	38	38.0	1	0.0000	3048.0	8.4

The remaining seven columns are inactive, indicated by a greyed-out appearance and '<0>' values for the Average parameter. Below the grid, there are several control sections:


- Distance UOM:** A dropdown menu set to 'micron'.
- Save Data to File:** A toggle switch set to 'ON'.
- Delay (sec):** A text input field containing '60'.
- File Name:** A text input field containing '% C:\grace tests\378_379_521.txt', with a 'Browse' button to its right.
- Points Saved:** A text input field containing '1430', with an 'RST' button to its right.
- Status and Debug:** A section containing a 'Current Process' field (empty), an 'Error Count' field containing '60', and a 'Sample Rate (readings/second)' field containing '10.1'.

MULTI-CHANNEL GRAPH

The **Multi Graph** tab simultaneously displays four live autoscaling charts.. The charts display 1000 points when fully loaded. Data averaging can be controlled and units of measure selected.

Each chart has drop down menus for

- » selection of sensor
- » selection of displayed parameter




MULTI-TRACE

The **Multi Trace** tab simultaneously displays three live autoscaling charts with Tared or Non-Tared Readings. The charts display 1000 points when fully loaded. Data averaging can be controlled and units of measure selected. *NOTE: Tare Reset can only be done at the Configuration Tab.*


Each chart has drop down menus for

- » selection of sensor
- » selection of displayed parameter



EXAMPLE: SETUP PROCEDURE

1. Use the Config Tab to setup each sensor prior to using Multi Trace
2. At Channel Select pick a sensor
 - a) Set The Optical Peak
 - b) Reset the Tare
3. Repeat For Each Sensor



DATA STREAM

The **Data Stream** mode enables continuous recording of data at high speeds. Default presets include:


- Time Stamp
- Reflectivity
- Temperature

5000 readings per second will be achieved as follows:

- set the BPS to 115.2 Kbps
 - set stream average to 1 (fast)
 - deselect the Time Stamp, Reflectivity and Temperature presets
- Click the **Stream Control** Button to begin saving data
Note: If you have not preselected a file, you will be instructed to browse to a file for saving the data. Use the file extension .txt when naming the file.

As data is streaming to the file:

- a) **Points Saved** ... accumulates the total number of readings
- b) **Sample Rate** ... displays the active number of readings per second



NEW CALIBRATION

The **New Calibration** tab can be used to create a new calibration for the sensor.

- At **New Calibration Slot**, select the calibration slot to be used
- At **Description**, enter a description of the calibration
- At **Distance UOM**, select the units of measure that will be used for the calibration distance
- Click Restart Calibration
- At **Calibration Point Distance**, enter the current distance between the sensor and the target
- Click **Take Sensor Reading**
- Repeat the previous 2 steps until the calibration is completed
- Click “Send New Calibration To Sensor”

DMS Setup and Control (version 1.21)

Com Port Configuration Multi Configuration Multi Graph Data Stream Burst Read **New Calibration** Admin

Serial: 679
Restart Calibration
New Calibration
New Calibration based on existing data

Calibration Instructions

1. Select Calibration slot. New calibrations will overwrite old data.
2. Enter a description for this calibration. (24 characters max).
3. Select UOM for the calibration distance that will be entered.
4. Click 'Restart Calibration Data' to restart calibration process. (will not change data stored on sensor).
5. Enter current distance between sensor tip and target.
6. Click 'Take Sensor Reading' or press 'Enter' key to save this calibration point.
7. Repeat steps 5 and 6 for each calibration point.
8. After last calibration point click 'Send New Calibration to Sensor'

New Calibration Slot: 10
Description:
Calibration Point Distance: 0
Take Sensor Reading
Calibration Points: 0
Send New Calibration to Sensor

Ratio
SNR

Distance

Distance UOM: micron
Save Data to File: OFF
Delay (sec): 1
Points Saved: 5621 RST
File Name: % C:\Documents and Settings\Jerry\Desktop\test.txt
Browse

Status and Debug
Current Process:
Error Count: 37
Sample Rate (readings/second): 5.1

PM

NEW CALIBRATION BASED ON EXISTING DATA

The **New Calibration** tab can also be used to rescale an existing calibration. Only one data point is required for scaling. Digital sensors are normally provided with two calibration tables: mirror and diffuse targets. Select the table which best fits a new target. For best accuracy, pick a scaling distance that is in the middle of the range of operation for the application.


- At **Reference Calibration Table**, select the reference table
- At **New Calibration Slot**, select the calibration slot to be used
- At **Description**, enter a description for the calibration
- At **Distance UOM**, select the units of measure that will be used for the calibration distance
- At **Calibration Point Distance**, enter the scaling distance between the sensor and the target
- Click **Take Sensor Reading**
- Click **“Send New Calibration To Sensor”**

The screenshot displays the 'DMS Setup and Control (version 1.21)' software window. The 'New Calibration' tab is active, showing a 'Serial: 679' field and a 'Restart Calibration' button. Below these are radio buttons for 'New Calibration' and 'New Calibration based on existing data'. A 'Reference Calibration table' dropdown menu is open, showing a list of calibration slots from 1 to 22, with '1: Mirror (specular)' selected. To the right, 'Calibration Instructions' are listed in a scrollable area. Below the instructions is a graph with 'Ratio' on the left y-axis (0.82 to 1.02) and 'SNR' on the right y-axis (0 to 100). The x-axis is 'Distance' (3.6 to 4.4). The graph area is currently black. At the bottom, there are input fields for 'Delay (sec)' (1), 'File Name' (C:\Documents and Settings\Jerry\Desktop\test.txt), 'Points Saved' (5621), 'Error Count' (37), and 'Sample Rate (readings/second)' (5.1). An 'EXIT' button is in the top right corner.


ADMIN - CALIBRATION TABLES

The **Admin-Calibration Tables** tab allows the user to inspect the stored calibration data in chart view and tabular forms.

Click on “**Send Calibrations To File**” to create a text file of a calibration table.




Calibration Table Display - Use this drop-down menu to select a calibration table for viewing and editing.



A calibration table includes three columns of data:

1. Distance - units are selectable at the UOM button
2. Ratio - the raw (unscaled) sensor output function
3. SNR - a measure of the signal strength/target reflectance



Distance	Ratio	SNR
0.000000	0.000000	6
50.799999	0.016940	71
101.599998	0.018750	148
152.399994	0.025790	183
203.199997	0.035510	197
254.000015	0.048620	203
304.799988	0.064250	204
355.600006	0.081030	204

CALIBRATION TABLES - EDITING

There are two sub-tabs: View and Modify.

In the View Tab calibration tables can be sent to a file or they can be copied to a clipboard.

DMS Setup and Control (version 1.46)

Com Port Configuration Multi Configuration Multi Graph Data Stream New Calibration Admin

Calibration Tables muDMS-Analog Setup Sensor Data Auto-Cal Select Firmware Update

Channel select
Serial:580 ch:1

Calibration table display
1: Mirror (specular)

Send Calibrations to File

View Modify

Copy Table to Clipboard

Table

Distance	Ratio	SNR
0.000000	0.000000	6
50.799999	0.016940	71
101.599998	0.018750	148
152.399994	0.025790	183
203.199997	0.035510	197
254.000015	0.048620	203
304.799988	0.064250	204
355.600006	0.081030	204

Number of Points
101

In the Modify Tab

- Calibration tables can be pasted from the clipboard
- The Calibration Description can be edited
- The Cal Table can be reset to original values if an error has been made
- The Calibration Gain (Sensor Gain) can be entered if known.

Sending Modified Calibration To Sensor

Before sending a calibration to the sensor, you must select a slot from the Calibration Table Display drop-down menu. That is where the modified calibration will be stored.

View Modify Distance

Table (Edit)

Distance	Ratio	SNR
0.000000	0.000000	6
50.799999	0.016940	71
101.599998	0.018750	148
152.399994	0.025790	183
203.199997	0.035510	197
254.000015	0.048620	203
304.799988	0.064250	204
355.600006	0.081030	204

Calibration Description
Mirror (specular)

Calibration Gain
20

Paste Table From Clipboard

Clear Table

Reset Table

Send Modified Calibration to Sensor

ADMIN - SENSOR DATA

The *Admin-Sensor Data* tab is used to view sensor information for factory diagnostic purposes.




ADMIN - AUTO-CAL SELECT

The **Admin-Auto-Cal Select** tab is intended for use in applications where 2 or 3 distinctly different targets are to pass by the sensor, and the distance measure to each of those targets is required.

When the **Admin-Auto-Cal Select** tab is in view, the sensor will lookup distance information from the stored calibration tables based upon the reflectivity of the target surfaces. For example, targets with a mirror-like finish (specular reflectors) have a different response than dull or diffuse reflectors, and therefore the two calibration tables are stored on board the sensor. The controls at this tab allow the user to select ranges of reflectivities of the targets that will be measured. The sensor will generate accurate distance information based upon the appropriate calibration table, as defined by the reflectance values. This function has no impact on the sensor sample rate.


Auto-Cal Select turns off when this tab is deselected.



ADMIN - Firmware Update

The **Admin-Firmware Update** tab is used to update the sensors internal firmware coding.

- Click the Firmware Update button. The Reset button will light and then turn off when Page writing commences. When page writing is finished (254 pages), the reset light turns on again as the sensor is refreshed. When the reset light turns off at this point, the update is complete.



KEYPAD/LCD OPERATION

When the **DMS** is first powered up, it displays the bar graph screen that was last displayed before the power down. For local operation, **DMS** systems have a two-tier display system:

1. A menu program for setup and selection of parameters and features



2. Active bar graphs for displaying measured results



MENU STRUCTURE

To move from the bar graph display to the menu, press and hold the MENU button for 1 second (This is the only keystroke requiring a press and hold). The **DMS** has a horizontally arranged menu structure. The top line of the display shows the present selection choice in brackets. The keypad buttons will do the following:

- MENU ... Returns to the active bargraph display
- < ... Scrolls left
- > ... Scrolls right

SELECT ... Opens the bracketed selection choice

The menu is arranged in the following order:

- Bar Graph Display
- Display Channel (for dual channel units)
- Distance Tare
- Reflectance Tare
- Calibration Slot
- Calibration Scale
- Gain Setting
- Temperature Set
- Units of Measure
- RS-232 BPS

DMS SETTINGS

The following parameters can be set or selected:

- Calibration Data Slot
- System Gain/Optical Signal Power
- Amplifier Temperature
- RS-232 Baud Rate
- Units of Measure


The following section gives detailed operating instructions for use of the keypad/LCD.

NOTE: For dual channel units, the LCD can be set (from the Display Channel Menu) to display channel 1 only, channel 2 only, or both channels 1 & 2.

OPERATING PROCEDURES

Reflectance Dependent Fiberoptics

With reflectance dependent fiberoptics, the optical signal power reflected from a target is proportional to the gap and to the reflectance of the target. The D Type sensor has a double valued output function called the near side and the far side regions. Operation in the near side region gives high sensitivity with limited range. Operation on the far side gives moderate sensitivity with much greater operating range.



The optical peak is where the reflected light signal strength reaches a maximum value. To make accurate distance measurements with these devices, the following procedure must be followed:

- 1 - Check Gain/ Signal Power
- 2 - Set Optical Peak
- 3 - Select Near Side or Far Side


Before any measurements are made, the sensor should be fixtured perpendicular to the target surface, the signal power checked, and the optical peak established. This procedure optimizes the signal strength and calibrates the sensor to the target surface to be measured. This is easily accomplished using the keypad/LCD on the DMS unit.

Keypad Procedure

1. Check Gain/ Signal Power Level

Scroll to the "Gain Setting" screen and press SELECT

- The top line shows the current Gain Setting
- The bottom line shows the Signal Power Level



PROCEDURE. At very close range to the target, vary the sensor gap and move to the highest Signal Power reading. At that gap position, use the cursor keys to increase or decrease the signal strength as needed. Adjust the gain to achieve the highest signal power safely without exceeding 100% signal power

press SELECT

The best performance is attained with the highest SPL.

Important! The Gain and Optical Peak Power are linked together. The optical peak MUST be reset any time the gain is changed to a new value.



2. Set Optical Peak

1. Scroll to the “Set Optical Peak” screen and press **SELECT**

The optical power is displayed on the top line.

2. Adjust the sensor gap to maximize the Optical Power reading. When the optical power is maximized, hold the sensor at that gap and press **SELECT**

Important! The Gain and Optical Peak Power are linked together. The optical peak **MUST** be reset any time the gain is changed to a new value.




MATERIAL	% REFLECTANCE
Gold Mirror	100
Mirror Polished Aluminum	85 - 90
Mirror Polished Stls Stl	60 - 70
Brushed Aluminum	40 - 50
Copper Clad PC Board	45
Finely Ground Steel	30 - 35
Anodized Aluminum	20 - 25
Silver Paint, Glossy	15 - 20
Photo Paper, High Gloss	15
inkjet Paper, Bright White	7 - 8
Fiberglass, Glossy	7
Black Plastic, Glossy	6
Black Matte Finish	3
Column of Water	2
Flat Black Rubber	1

The table here shows the relative reflectance of some common materials.

3. Select Near Side or Far Side

The DMS does not automatically know which side it is on. The user must set the DMS to measure on the near side or set it to measure on the far side.

- Scroll to the Bar Graph Display.
 Move the cursor to *near* or *far*
 Press **SELECT**



Keypad/LCD Details

BAR GRAPH DISPLAY

The choices for *dual channel* bar graph displays are:

1. Distance only both channels
2. Reflectance only both channels

The choices for *single channel* bar graph displays are:

1. Distance Only
2. Reflectance Only
3. Distance & Reflectance
4. Total Runout, T.I.R.
5. Peak-to-Peak Distance Amplitude, 40 Hz to 5 KHz
6. Peak-to-Peak Distance Amplitude, 4 Hz to 5 KHz

In this display an asterisk highlights the selection choice.

MENU ... Returns to the main menu

< ... Moves asterisk left

> ... Moves asterisk right

SELECT ... Sets the bar graph display to the asterisked item

Note: The select key must be pressed to activate a new selection. Pressing the menu key returns to the main menu without saving the new selection.

BAR GRAPH DISPLAYS

1 Channel *DISTANCE ONLY*

The upper line displays 3 values:

- the start of the measurement range, 0.00
- the active sensor-to-target distance
- the upper limit of the DMS measurement range

The lower line is an active distance bar graph.

2 Channel *DISTANCE ONLY*

Channel 1 on Top Line, Channel 2 on Bottom Line

Note: mils = mINCH = 0.001"

REFLECTANCE ONLY

The upper line displays three values:

- zero
- the active percent reflectance relative to the loaded calibration target material
- 100%

The lower line is an active reflectance bar graph




DISTANCE & REFLECTANCE

The upper line displays:

- The active distance measurement with active bargraph

The lower line displays:

- The active reflectance measurement with active bargraph



BAR GRAPH DISPLAYS CONTINUED

TOTAL INDICATED RUNOUT, T.I.R.

When T.I.R. is selected from the Bargraph Display menu, a two-line display is presented that gives 5 numbers:

Top Line		
Minimum Value	Tared Distance	Maximum Value
Bottom Line		
Absolute Distance		T.I.R.



where T.I.R. = Maximum Value - Minimum Value.

The left or right cursor keys, when depressed, will reset the T.I.R. Values to zero.

NOTES:

1. The T.I.R. function is intended for slowly moving parts such as the manual rotation of a shaft. It is limited to movements at 10 Hz and slower.
2. T.I.R. can be used with or without the distance tared, however it makes more sense to use this function when the distance reading is tared to zero before motion starts.

PEAK-to-PEAK VIBRATION AMPLITUDE

Peak-to-Peak amplitude of vibrations can be measured with one of two high pass filters:
40 Hz - 5 KHz and 4 Hz - 5 KHz.

These two displays will appear exactly like the distance only displays. The LCD is refreshed 4 times per second, displaying the pk-pk amplitude of 4092 readings taken every 1/4 second.

DISPLAY BRIGHTNESS AND CONTRAST

The display brightness and contrast levels can be adjusted while viewing any bar graph display.

While viewing any bar graph display, press the select button to bring up the contrast and lighting screen shown here.

Press the select button again to switch between contrast and lighting.

Use the arrow buttons to increase or decrease the levels.

Press the menu button to return to the bar graph display. The new settings will be saved.



Note: The display brightness can be totally turned off to reduce power consumption as in a "Sleep Mode".

DISTANCE TARE

The distance tare feature sets the current measured value to zero. The active bar graph remains in the untared mode. To Tare to the current measured value:

move the asterisk to "reset-on"
Press SELECT

Off is used to turn off the tare function
On is used to turn on the tare to the previously selected tare value.

NOTE: When the tare function is on, a plus or minus sign is placed in front of the active tared value, and, the tared value is displayed on the distance tare setup screen.




REFLECTANCE TARE

The reflectance tare feature sets the current measured value to 100%. The active bar graph remains in the untared mode. To Tare to the current measured value:

move the asterisk to "reset-on"
Press SELECT

Off is used to turn off the tare function
On is used to turn on the tare to the previously selected tare value.

NOTE: When the tare function is on, a plus or minus sign is placed in front of the active tared value.



SELECT CALIBRATION TABLE

This screen is used to select which calibration table the system will use for distance lookup. Twenty four (24) characters are available to describe the calibration data. The factory supplied calibrations are stored in slots 1 & 2. Thirty one (31) slots are available for storage. Each slot can store up to 256 data points.


Scroll < or scroll > to the desired cal table
Press SELECT The cal table will be loaded for use.



CALIBRATION SCALING

Scaling of the sensor calibration data is useful for two purposes:

1. It can be used to reset the sensor calibration accuracy if the DMS system sensitivity has drifted over time or temperature.
2. It can be used in place of an actual distance calibration, to rescale the DMS calibration data to a different target material for which a calibration does not exist.



USING KEYPAD

Using the keypad only, the Scaling Gap MUST be equal to the sensor's maximum operating distance. To rescale the selected calibration that has been loaded:

- a. Gap the sensor to the maximum distance from the target
- b. From the main menu, scroll to Calibration Scale and press SELECT
- c. The display will show the master distance and the (active unscaled distance measurement). Note the active reading. If it is not correct, scaling is needed.

USING PC

Using a PC keyboard, any gap can be used for Calibration Scaling. To rescale the selected calibration that has been loaded:

- a. Set the master distance via a serial port command (see RS232 command instruction set)
- b. Gap the sensor to the master distance from the target
- c. From the main menu, scroll to Calibration Scale and press SELECT
- d. If the unit is a 2-channel DMS, select ch. 1 or ch. 2
- e. The display will show the master distance and the (active unscaled distance measurement). Note the active reading. If it is not correct, scaling is needed.
- f. Move the asterisk to "reset-on"
- g. Press SELECT
- h. Return to your bar graph display and note the active reading is now correct.

Off is used to turn off the scaling function


On is used to turn on the scaling to the previously selected value.

GAIN SETTING*

- The top line shows DMS internal gain.
- The bottom line shows the strength of the signal returned from the target under measurement.

PROCEDURE. Move the sensor thru its operating range and note the highest reading. Use the cursor keys to increase or decrease the signal strength as needed. Adjust the gain to achieve the highest signal power safely without exceeding 100% signal power.

*Note: If the target is very dark, SPL below 5%, a higher gain setting will increase the signal strength and will improve resolution




TEMPERATURE READ and SETTING

This display gives the temperature set point on the upper line and the active temperature measurement on the lower line. The units are always °C.

PROCEDURE FOR TEMPERATURE STABILIZATION

- Power up the DMS and allow it to reach an equilibrium temperature.
- Use the cursor keys to set the temperature 2-3 degrees above the equilibrium temperature
- Press SELECT
- The DMS temperature will be maintained at the set temperature $\pm 0.1^{\circ}\text{C}$ in normal ambient room temperature conditions




Occasionally check the active temperature. If ambient conditions change and the active temperature exceeds or falls below the Set Temperature, the Set Temperature must be reset to regain temperature control.

UNITS OF MEASUREMENT

Scroll < or scroll > to the desired units

Press SELECT



SELECT RS232 BAUD

Scroll < or scroll > to the desired baud rate

Press SELECT

Note: A custom baud rate can be selected by the keypad, but the value of the custom baud must have been preset by using a PC terminal.

